


**1278 Pump head**  
**2076 External filter**  
**2078 External filter**




Spare parts. Subject to change without prior notice.



**1278 Pump head**  
**2076 External filter**  
**2078 External filter**



Spare parts. Subject to change without prior notice.



Order no.	Spare part	2076 / 2078
1278000	Pump head complete for 2076 / 2078 (without adapter and transformer)	
2616760	Set 1 x filter pad and 4 x fine filter pads	
4005710	Outlet pipe	
4005943	Hose, pressure and suction side ø 16/22 mm (3 m)	
4015150	Suction cup with clip (2 pieces)	
7212108	Lattice screen	
7212258	Hose clamp complete	
7212538	Transformer	
7221058	Sealing ring for pump cover	
7271958	Rubber feet set (5 pieces)	
7275808	Intake pipe	
7343858	Outlet jet pipe	

Order no.	Spare part	2076 / 2078
7428580	Valve with holder	
7428590	Shaft with bushings and distance sleeve ( <b>electronic</b> )	
7428608	EZ clips complete	
7428630	Separation screen with sealing ring for 2076	
7428640	Separation screen with sealing ring for 2078	
7428658	Filter media container	
7428668	Prefilter complete with valve and sealing ring	
7428670	Set of sealing rings (for pump and canister)	
7428680	Set of sealing rings (for adapter and separation screen)	
7428690	Pump cover complete with sealing ring and bushings	
7428700	Filter canister with side protection for 2076	
7428730	Filter canister with side protection for 2078	
7428718	Adapter complete	
7428728	Floater complete	
7447150	Set of pipe plugs	
7471800	Inlet strainer	
7603220	Impeller for 50 Hz and 60 Hz ( <b>electronic</b> )	